

WANDERTEC INC.

B.O.B. Yak/Greenspeed rack adapter kit

Tools You will need:

4mm allen key, 8mm wrench, and grease

Parts List:

2x M5 x 30mm bolt

2x M5 x 12mm bolt

2x M5 x 15mm washer

4x M5 x 10mm washer

2x 10mm standoff spacer

2x M5 nylock nuts

1x Rubber shim (optional)

1x Adapter bracket assembly, includes:

1x Adapter bracket

1x Tube clamp

2x Tube clamp washers

2x M5 x 15mm bolt

2x M5 nylock nuts



Please read these instructions all the way through before you begin. Then **grease the threads on all the nuts and bolts** and get started.

1. Attaching the adapter bracket assembly to the cargo stop bar

Disassemble the adapter bracket assembly, grease the bolt threads, and reassemble it with the tube clamp wrapped around the cargo stop bar (on the rear of the trailer). You may place the rubber shim between the clamp and the luggage bar to protect the paint. Don't tighten the nuts all the way, as the whole assembly will be rotated later.



2. Attaching the Greenspeed rack to the trailer dropout eyelets

Put a little dab of grease in the trailer eyelet. Then put an M5 x 10 mm washer on a M5 x 30mm bolt, and slide the bolt through the lower eyelet on the rack. Put a 10mm standoff spacer on the bolt, and carefully thread the bolt into the trailer eyelet, taking care not to cross threads. Repeat this process on the other side. Level the top of the rack, and snug up the bolts. The fender struts go on the threads protruding inside of the dropouts. Use an M5 x 15mm washer and a nylock nut to secure them. When tightening these nuts, it is **really important that the bolt is snug, and that you hold it in place with an allen key while tightening the nut**. If you don't, the bolt will loosen, and the trailer eyelet threads could be damaged when the rack is under load.



3. Attaching the adapter bracket to the upper rack eyelets

Align the holes in the upper rack eyelets with the adapter bracket. Put a M5 x 10mm washer on a M5 x 12 mm bolt, slide it through the rack eyelet, and thread it into the adapter bracket. Repeat this process on the other side

4. Finishing up

Tighten the adapter assembly clamp on the cargo stop bar. Double-check all your fasteners, (especially the 30mm bolts at the trailer dropout eyelets!).



Wandertec, Inc.
2505 N. Center St.
Flagstaff, AZ 86004
800-717-2596
info@BikeTrailerShop.com